



Contents

Preface.....	5
Coordinate systems and units in the CAD environment	6
Drawing units	6
S-JTSK coordinate system in the AutoCAD environment.....	8
Creating a new coordinate system.....	13
External references.....	19
External references and units of the drawing	20
Attaching the external references	20
Management of the external references	23
Displaying the changes in the external references	24
External references and units of the drawing	26
Layers of the external references	27
Setting the base point of the drawing	29
External reference of the “Attachment” type	30
Working with the blocks	33
Creating the block	33
Modification of the block.....	37
Using blocks in multiple drawings.....	39
Change of the block definition.....	44
Blocks with attributes.....	45
Using the layers.....	50
Basic layer settings.....	50
Layer filters	55
Other tools for working with layers	55
Working with layers and blocks.....	57
Using the tables	61
Basic properties of the tables	61

Creating a new table.....	62
Basic table adjustments and operations.....	65
Fields	68
Inserting fields into the text objects	69
Inserting the fields into the attributes.....	71
Inserting the fields into the tables	73
Field linking	74
Possibilities of linking CAD and MS Excel.....	75
Creating a link to the table	75
Inserting the table in the drawing.....	77
Editing the existing data link.....	79
Updating the imported data	80
Editing the linked table and using the formulas.....	81
Possibilities of linking CAD and GIS	83
Importing the CAD data into the GIS environment	83
Exporting the GIS data into the CAD environment	86
Advanced printing options	89
Drawing sheet - Layout.....	89
Using the viewports.....	91
Layers and viewports	96
Scale of the drawing viewport with various units and the coordinate systems of the viewports.....	99
Creating the scripts.....	101
Creating the path from the geodetic measurement.....	103
Inserting the blocks and filling in the attributes using the script	105
References	109